TheFinancialPhoenix.com

Old Houses. New Beginnings. Financial Freedom.

Step by Step

DIY Painted Floor



Time: About 2 Hours total

Cost: **\$107**

Supplies

- TSP (or your preferred cleaner)Paint
- Stencil
- Stencil Brush
- Towel
- Paper Plate
- Sealer
- Shark Grips (optional)

Preparation

- 1. Sand any rough/uneven spots
- 2. **Wash floor** with TSP or your preferred cleaner and let it dry
- 3. **Test Stencil Placement** with a dry fit (no paint) and use tape or chalk to mark the starting location
 - Consider how the stencil will fit both across and along the floor after fixture (tub, toilet) placement
- 4. **Pour** a *small* amount of paint on a paper plate
- 5. **Practice** with the stencil and brush on a scrap surface
 - Use a dry brush technique and blot off any access paint on a towel before applying to stencil
- Take a deep breath and start painting with the stencil using a vertical dabbing motion
 - Ensure you work your way out of the room when painting
 - Be careful not to slide the stencil when lifting it
- 7. **Line up** the next placement using the guides on the stencil
 - Don't stress about small imperfections. It's called character.
- 8. **Mix Shark Grip** and sealer to the manufacturer's recommended ratio
- Apply sealer according to manufacturer's directions
- 10. **Enjoy** your beautiful, durable floor!